


MODEL : LU-G40LAC



PARTS LIST (LU-G40LAC)

*WHEN ORDERING SPARE PARTS, PLEASE STATE ITEM No, PART NO. AND DESCRIPTION.

ITEM	PART NO	DESCRIPTION	QTY	ITEM	PART NO	DESCRIPTION	QTY	ITEM	PART NO	DESCRIPTION	QTY
01	HS05080BW-20	HEX. SOC. HD. BOLT+SW	4	49A	17104901A	STAPLE GUIDE UNIT	1				
03	13900306	CAP	1	50	14305001	MAGAZINE	1				
04	12100401	SEAL**	1	51	14305101	PUSHER	1				
05	12100501	SPRING**	1	52	14305201	SLIDE BLOCK	2				
06	OR13824N	O RING**	1	53	11305301	SPRING**	2				
07	11100701	CAP SEAL**	1	54	11305401	ROD	2				
08A	13900801A	HEAD VALVE ASM.	1	55	11305501	SHAFT	1				
11	OR31824N	O RING**	1	56	11305601	SET BLOCK	2				
13-1	OR25735N	O RING**	1	58A	12505801A	END CORE ASM.	1				
13-2	13901305	PISTON RING	1	59	US05080B-10	UM. HD. BOLT	4				
14A	18301401A	DRIVER ASSEMBLY**	1	63	HS04070B-10	HEX. SOC. HD. BOLT	2				
18	OR44431N	O RING**	1	64	HS05080B-16	HEX. SOC. HD. BOLT	1				
19-1	13301901	CYLINDER	1	65	LN0500N	LOCK NUT	1				
19-2	13301901G	CYLINDER	1	66	11106601	COVER	1				
19-3	13901903	COLLAR	1	67	12106401	AIR PLUG	1				
20	13902001	BUMPER**	1	68	OR40030N	O RING**	1				
21	OR35020N	O RING**	1	69	12706901	BRACKET	1				
22	OR35735N	O RING**	1	71	US05080B-06	UM. HD. BOLT	1				
23	11102309	BODY	1	72	FW050120B-08	FLAT WASHER	1				
24	OR01919N	O RING**	2	73	12103301	SEAL	1				
25	17102501	JOINT GUIDE	1	74	13907403	EXHAUST COVER	1				
26	11002601	SPRING	1								
27	11002701	GUIDE SAFETY LEVER	1								
29	LN0300N	LOCK NUT	1								
30	CH03050B-08	CAP. HD. SCREW	1								
31	12703101	SAFETY LEVER	1								
32	11103201	STEPPED PIN	2								
41	HS04070B-06	HEX. SOC. HD. BOLT	2								
42	11604201	NOSE COVER	1								
43	HS04070B-16	HEX. SOC. HD. BOLT	2								
44	HS05080BW-25	HEX. SOC. HD. BOLT+SW	2								
46	14304601	NOSE	1								
47	11304701	SET PLATE	1								
48	12504801	SET PLATE	1								